



### Commonly Observed Milking System Opportunity Areas

- Inappropriate claw vacuum settings
- Unstable milkline vacuum
- Issues after claw or liner change
- · Challenges with the retraction event
- Inappropriate use of manual mode

Cornell University Animal Health Diagnostic Center

Quality Mill

### Inappropriate Claw Vacuum Settings

- Has the average claw vacuum at peak flow for a 5 to 20 second interval been accurately measured on at least 10 cows?
- Is it appropriate for this herd?
  - Goals of the dairy
  - Liners
  - Risk of over milking (milking routine, ATO settings, unit alignment, etc)



Quality Milk

Cornell University Animal Health Diagnostic Center

### Inappropriate Claw Vacuum Settings

- 1000 cow herd with a double 20 parallel parlor
- Increasing clinical mastitis and bulk tank somatic cell count (SCC)
- Hardness at teat end = 50% abnormal
- Teat end score = 35% abnormal
- Farm vacuum gauge broken




Quality Milk

### Inappropriate Claw Vacuum Settings

- Average claw vacuum was 13.3"Hg (45.1 kPa)
- Liner manufacturer wants 11.5"Hg (39 kPa)
- Conference call with owner and equipment dealer before leaving farm
  - Plan to drop vacuum 1"Hg (3.4 kPa) in 2 steps
- Recheck claw vacuum



Quality Milk




Animal Health Diagnostic Center


Quality Milk


### Unstable Milkline Vacuum Levels 100 cow herd in a swing 12 parallel parlor Primary complaint is high SCC System passes a 1 unit fall-off test and has enough effective reserve. Pump capacity is adequate and system loss is 5%. 6 units per slope with a 2.5" (60 mm)


milkline


Cornell University Animal Health Diagnostic Center

















	Previous set-up	New claws, shells, and liners	After adjustments
Claw vacuum ("Hg/kPa)	12.2/41.4	12.1/41	11.8/40
Pulsator rate	60	60	60
Pulsator ratio	60:40	65:35	60:40
b phase (ms)	450	496	442
d phase (ms)	235	186	226



### **Inappropriate Retraction Event**

- 950 cow herd milking in a double 16 parallel parlor
- Short term teat scores showed 46% with hardness at teat end
- Retraction event was a problem on 9 out of 32 units



Quality Milk

### Inappropriate Retraction Event



 Dealership contacted that day to work on shut-offs

Cornell University Animal Health Diagnostic Center


Quality Mill


# Inappropriate Retraction Event 1400 cows in a double 24 parallel parlor Issue is SCC is higher than the farm wants Milking time audit showed milkers struggling to get retraction chain to release on some units Retraction chain catching on some units during retraction and cluster hitting the deck





### Inappropriate Retraction Event 1300 cow dairy with double 20 parallel parlor Increase in SCC is primary complaint Switched to liners with vents in mouthpiece chamber a while ago Many units hit the deck on retraction Vacuum decay time set to zero












 Over 40% of milkers reported no training or unsatisfied with the training on milking equipment

Cornell University Animal Health Diagnostic Center

Quality Mill

Quality Milk




### Prevention of Problems


- <u>Scheduled</u> maintenance needs to happen!
  - Equipment runs 24/7
  - Insurance policy
  - Internal vs External
  - Another set of eyes

Cornell University Animal Health Diagnostic Center

- Communication of findings



8



## Summary Perform a detailed analysis on a regular basis to provide accurate data to the milk quality team meetings Prioritize the equipment issues detected and work with owner and dealership to get them corrected Help the farm train employees on detecting equipment problems and establishing a good communication channel for these problems

